



<p>1</p> <p>Diagram 1: Disassembly of the fixture cover. The cover is shown being removed from the main body of the fixture. A screwdriver is used to remove the screws (I) and the cover (II) is lifted.</p>	<p>2</p> <p>Diagram 2: Mounting the fixture to the ceiling. The fixture is shown being attached to the ceiling using two screws. A screwdriver is used to tighten the screws. A warning icon shows a red button with a lightning bolt and the word "OFF".</p>
<p>3</p> <p>Diagram 3: Electrical wiring connection. The fixture is shown with the wiring connected to the ceiling. A screwdriver is used to tighten the screws (I) and the cover (II) is pushed back on. A circular inset shows the wiring terminals (L, N, PE) and the connection point (push).</p>	<p>4</p> <p>Diagram 4: Final assembly and power on. The fixture is shown fully assembled. A warning icon shows a green button with a lightning bolt and the word "ON".</p> <p>Źródło światła zastosowane w tej oprawie oświetleniowej powinno być wymieniane wyłącznie przez producenta lub jego przedstawiciela serwisowego, lub podobnie wykwalifikowaną osobę.</p> <p>The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person.</p>



Ten produkt zawiera źródła światła o klasie efektywności energetycznej E.
This product contains a light sources of energy efficiency class E.

LED
int